Digital Signage User's Guide

Features:

- 1, through the Windows desktop software (CS architecture) management terminal, simple operation, fast response, stable operation
- 2, the player terminal Android-based, feature-rich, stable operation
- 3, the content server hierarchical deployment, the control server clustering services to support the number of terminals expand as needed

INTRODUCTION FUNCTIONAL OVERVIEW	5
CHAPTER 1 INSTALLATION AND CONFIGURATION	7
1. 1 SERVER INSTALLATION	7
1. 3 Installation Management tool	11
1. 4 CONFIGURATION MANAGEMENT TOOL	14
1. 4. 1 SETTING CONTROL SERVER IP	14
1.5 INSTALL THE PLAYER TERMINAL	15
1. 6 CONFIGURATION PLAYER TERMINAL	16
1. 6. 1 Set the server IP	16
1. 6. 2 SETTING THE TERMINAL NUMBER	17
1. 6. 3 SINGLE MANUAL REGISTRATION	18
CHAPTER 2 MATERIAL MANAGEMENT	19
2. 1 AUDIO AND VIDEO UPLOADING	20
2. 2 UPLOAD PICTURES	20
2. 3 UPLOAD TEXT	21
2. 4 UPLOAD UPGRADE PACKAGE.	21
2. 5 ADD WEBSITE	22
2.6 MATERIAL (FILE) PREVIEW	22
2.7 Modify the file duration	23
2. 8 UPLOAD PROGRESS	23
CHAPTER 3 PROGRAM EDITING	24
3. 1 CREATE PROGRAM.	24
3. 2 OPEN PROGRAM.	26
3. 3 SAVE PROGRAM	26
3. 4 Program Save as	27
3. 5 SAVE TEMPLATE	27
3 6 PROGRAM PREVIEW	27

	3. 7 RELEASE PROGRAM	28
	3. 8 Export Program	29
	3. 9 CLOSE PROGRAM	32
	3. 10 CHANGE BACKGROUND	32
	3. 11 DELETE BLOCK	33
	3. 12 CHANGE RESOLUTION	33
	3. 13 FINE TUNE	34
	3. 14 ELEMENT PANEL	34
	3. 15 EDITING BLOCK CONTENT	35
	3. 16 PLAY SETTINGS PANEL	36
	3. 17 LINK PROGRAM	37
	3. 18 BLOCK TO FULL SCREEN	38
C	HAPTER 4 PROGRAM REVIEW 3	9
	4. 1 AUDIT PROGRAM INTERFACE	39
	4. 2 REVIEW PROGRAM	39
	4. 3 AUDIT PROGRAM	11
	4. 4 DELETE PROGRAM	12
	4. 5 Preview Program	13
	4. 6 RELEASE PROGRAM	13
C	HAPTER 5 TERMINAL MAINTENANCE4	6
	5. 1 ADD TERMINAL GROUP	16
	5. 2 Modify Group	16
	5. 3 DELETE GROUP	17
	5. 4 MOVE TERMINALS	18
	5. 5 Remove Terminal	18
	5. 6 STATUS MONIT	19
	5. 7 Configure Terminal	19
	5. 8 REMOTE SHUTDOWN	52

	5. 9 Reboot
	5. 10 ShutOn
	5. 11 REMOTE SCREENSHOT
	5. 12 REMOTE UPGRADE
	5. 13 Network Registration
C	HAPTER 6 TERMINAL RELEASE56
	6. 1 RELEASE PROGRAM
	6. 2 VIEW PROGRAM
	6. 3 INSERT-PLAY SUBTITLES
	6.4 INSERTION-PLAY PROGRAM60
	6.5 CANCEL INSERTION PLAY
	6.6 TERMINAL FILE
	6.7 DELETE FILES
	6.8 DOWNLOAD PROGRESS63
	6. 9 PLAY LOGS
	6. 10 TERMINAL RUN LOG
C	HAPTER 7 FTP USER66
	7. 1 ADD FTP USER
	7. 2 Modify FTP User
	7. 3 DELETE FTP USER67
C	HAPTER 8 ROLE MANAGEMENT68
	8. 1 ADD ROLE
	8. 2 MODIFY ROLE69
	8. 3 DELETE ROLE
C	HAPTER 9 USER MANAGEMENT70
	Q 1 App Herp 71

	9. 2 MODIFY USER	.72
	9.3 Delete User	.73
C	HAPTER 10 LOG ANALYSIS	75
	10. 1 PLAY LOG	. 75
	10. 2 RUN LOG	.75
	10. 3 OPERATION LOG	. 76
C	HAPTER 11 SYSTEM MANAGEMENT	.77
	11. 1 Modify System Settings	.77
	11.2 Modify Settings.	.77
	11.3 Modify Password	. 78
	11. 4 EXIT MANAGEMENT TOOL	. 79
C	HAPTER 12 SOFTWARE UNINSTALL	.80
	12. 1 Uninstall Management Tool	. 80
	19 9 Uninctali Server	ደበ

Introduction Functional Overview

1. Play format

Support for playback of video, pictures, FLASH, PPT, WORD, EXCEL, marquee, text, audio and other content, can play alone, or a combination of divided screen playback.

2, design

WYSIWYG visual editing programs, free split screen area combination. Advanced system architecture, small-generated program file, save transmission bandwidth.

3, support for interactive

Links between the support program jumps and timed automatic return, powerful interactive features, publish and interact with the perfect combination.

4, release management

Specified period of time the program published to the specified playback end group. You can set the program play mode and schedule, etc., the program supports breakpoint continuingly and background downloading methods, reliable transmission.

5, the terminal management

You can set the default program automatically play, player terminals when the player does not receive a new schedule, according to the default program. Real-time Insertion-Play: The system can play emergency program, announcements rolling subtitles. Terminal Management: The system can be remote playback end time proofreading, regular boot, shutdown or sleep, remote volume control, player terminal's hard disk space management operations.

6, user rights

User Management: Manage user accounts, permissions, and passwords, records related tasks and activities.

Rights Management: The system provides multi-level rights management, to meet the needs of large organizations hierarchical management control processes. For system administrators, publishing manager, administrator and other audit programs.

7, program approval

Once you've created the program review process can be set only after a review of the program before they can publish. The system administrator can make an administrator, edit or modify the content of the program, set for an administrator to submit a review and can not be released directly.

8, monitoring and management

System for the entire network and each player terminal hardware and software for real-time monitoring, including network connection status, playback end state, currently playing program, the current insertion-play, program information, client update information. The situation is abnormal alarm.

9, statistical analysis

The system provides large enterprises need specialized statistical reports, statements such as playing time, program-play frequency of reporting, monitoring daily report, the failure rate of reporting. The system records the work of a variety of important events, including: Download the program task and play records, playout errors and exceptions and other logs.

Chapter 1 Installation and Configuration


1.1 server installation

Package: XDSSetup xxxxxxxx.exe

The installation process: Double-click the installation package, launch the installer, as shown below:




Step 1: Select Language




Step 2: Description




Step 3: License Agreement



Step 4: Select installation components, the server contains four components, the default Select All under normal circumstances



Step 5: Select the installation path, to avoid the system disk permissions problem, installed by default in the D drive, click [installation], the installation process takes about two to three minutes




Step 6: Click [Finish], the program will start automatically.


☆ Analyzing server program is running:

and are displayed, and cast a red cross or shadow showing the system program is started normally.

XDS Control Server main interface:



FTP Server main interface:



1, background check service is started, a total of four services: XDSServer, MySQL, FileZilla, Apache, Enters System Services, right-click [Computer] → [Management] → [Services and Applications] → [service] to check the status of service, as shown below:

XDS Apache	Started	Automatic	Local Syste
XDS Control	Started	Automatic	Local Syste
XDS FileZilla	Started	Automatic	Local Syste
XDS MySQL	Started	Automatic	Local Syste

1.3 Installation Management tool

Package: XDSToolSetup xxxxxxxx.exe


The installation process: Double-click the installation package, launch the installer, as shown below:




Step 1: Select Language




Step 2: Description



Step 3: License Agreement



Step 4: Select the installation path



Step 5: Install complete

1.4 Configuration Management tool

1.4.1 Setting control server IP

After installation is complete, double-click the desktop icon [XDS Tool], start the management tool, enter your user name and password, click on Settings to modify the server IP, as shown below



Account: admin
Pasw:

Setting

Login

Language: English
Server IP: 127.0.0.1

Server Port: 5000

• initial user name and password are both "admin".

- server default IP is 127.0.0.1, should be amended to the actual IP address, the port is 5000.
- When the management client and the server is not installed on the same computer, server IP field fill in the IP address of the server computer. When the server is deployed here to fill in the WAN IP address at WAN, server when deployed in a local area network LAN is fill in the local IP address. Click [Login], enter the management tool of the main interface, as shown below



☆ If the management tool and the server connection is not successful, the prompt:



Please check the reason in the following order:

- 1. check the server XDSServer service is started;
- 2. check managment tool settings server IP, port number, user name, password is correct;
- 3. Check the management-server network is normal, you can use Ping command to test;
- 4, check the server's firewall is turned on port 5000~5100;

1.5 install the player terminal


Installation file: XdsAssist_xxxxxxxx.apk and XdsClient_xxxxxxxx.apk

Installation process: copy the installation files to the U disk or SD card, and then

inserted into the terminal, then click Install XdsClient and XdsAssist


1.6 Configuration player terminal

Plug a mouse or keyboard into player terminal, clicking a mouse's middle button or press [F10] key, click [setting] button to enter the configuration interface, as shown below



1.6.1 Set the server IP

Click the middle mouse button or press [F10] key and click [server IP], popup server IP dialog, enter the server IP, click OK, as shown below




After clicking OK, the status display "Connecting" to display the "successful connection", after a successful connection, while the management tool of the [terminal manager] window will add a new terminal record.

☆ Player terminal and server connection is not successful, the system prompts "connection failed", please check the reason in the following order:

- 1, check whether the player terminal's network is well, set [System Settings] WiFi or Ethernet;
- 2. Check terminal's setting server IP, port number is correct;
- 3, check the server XDSServer service is started;
- 4, check the server to the player terminal of the network is normal, try to play Ping terminal's IP from server-side;
- 5, check the server's firewall is turned on the port 5000-5100;

1.6.2 Setting the terminal number

Click the middle mouse button or press [F10] key, click terminal number, will pop up dialog box, enter a number value, and click OK



Terminal number is a unique number in the background terminal management system, in order to distinguish between different terminals, management background in number to identify the terminal. The number's default length is 8, composed of letters and numbers.

1.6.3 Single manual registration


The player terminal supports registration when offline, follow these steps:

Step 1: transcribing machine code, click the middle mouse button or press the F10 key to enter the terminal settings interface, view terminal machine code, machine code composed from the 20 letters and numbers, as shown below

Software Registration Machine Code:NDFDQ-0FFMZ--MXMTY--2NZY= Unauthorized

Step 2: the machine code is sent to manufacturers, vendors returned registration code


Step 3: Enter the terminal settings screen, click [Register], pop-up dialog box, enter the registration code and click OK. If registration code is correct, the system will prompt "authorization success", as shown below:



\$\times\$ generally before leaving factory the player terminal has been registered. While a large number of terminals may be employed the part 5.13 [network registration] described batches were quick registration, both equally effective.


Chapter 2 Material Management


Material management mainly for materials used in the program and the upgrade package to add, delete, rename and other operations, according to the type of material can be divided into audio and video, flash, images, text, office documents, web sites, upgrade packages. Click the main menu bar of the "material management" button to display material management window, as shown below



2.1 Audio and video uploading


Click on "audio and video" sub-page, → click Add button, then choose to upload audio and video files, as shown below:






2.2 Upload Pictures

Click on "Pictures" subpages, click Add button then select the picture you want to upload, as shown below:




2.3 Upload text

Click the "Text" sub-page, click Add button then Select the text file you want to upload, as shown below:




2.4 Upload upgrade package

Click "upgrade package" sub-page, click Add button, then choose to upload the upgrade package, as shown below:




2.5 Add Website

Click the "WebSite" sub-page, click Add button, then enter the site name and URL, as shown below:




2.6 Material (File) Preview

Click to preview material, automatically display the contents of the preview area, as shown below:



2.7 Modify the file duration


Choose to modify the length of the material, and then edit the length of the input value box, as shown below:



☆ The duration of video file had been added automatically calculated, and if found that the actual length of time to play is inconsistent, then can be modified here.


2.8 Upload progress

After the file is added, it will be simultaneously displayed in the progress bar upload progress, as shown below:



Chapter 3 Program Editing

Program is a layout arrangement consisting of a playback unit defined by a number of material, program editing can modify the resolution, background, area size and position. Program editing interface as follows:



3.1 Create program


Click [Create] button to open the wizard to create a program, enter the relevant properties:


Program Name: The name of the program, unique

Resolution: The width and height of the program, must be consistent with the resolution of the player terminal (if be inconsistent the program will display beyond the screen or bottom right of the screen appears blank).

Direction: binding resolution, select [lateral] or [Portrait]

Background: [template] retrieval of previously saved template; [Picture] use a picture file as a background; [None] no background






 \Rightarrow If the resolution is not in the list you want to target resolution setting, you can manually enter a resolution value, simply press the "long x wide" mode settings.

3.2 Open program

Click the [Open] button then select the program. As shown below:




3.3 Save program

Click Save button then enter the program name, as shown below:




3.4 Program Save as

Click [Save] button then enter the program name, as shown below:




3.5 Save Template

Click [Save Template] then enter the template name, you can save up the template of the current program for future reuse templates including background and blocks, but does not include block file. As shown below:




3.6 Program Preview

Click [Preview] button, you can preview the current program. As shown below:




3.7 Release program

Click [Release] button, pop-Release program guide, the first step choose to publish to which the terminal group, the second step select the playback start and end dates and times, as shown below



Step 1: Select release to the groups



Step2: Set play star date/time and date/time

[Priority (Insertion)] Check this box indicates the program on the selected terminal group takes precedence over the same group unchecked programs, should be noted: the same period of time if the terminal groups on both high-priority programs and lower priority programs, the terminal will only play high-priority programs.


[Download Immediately] when received the command, the terminal will be immediately download the files included in the program from the server;

[free download] represents the period after the command is issued, the terminal will not be downloaded immediately, but wait until the free period of time to download, has avoid the congested the network in busy periods.


☆ If the program has not saved click on the [Release], it is automatically saved to re-release, the program will pop up a dialog box prompts for the name if the program name is not set.

3.8 Export Program


With exporting program function in the case of the terminal offline, when terminal can not connect to the server so that it can not updates the playing file from the server, in which case the program should be exported from the management tool through the U disk, Click [Export] button to bring up the Export Wizard program, the first step is selecting the program's playing date and time, the second step is select a saved directory, the third step to begin the export, display real-time progress of the export, as shown below:



Step 1: Set playing date and time



Step 2: Select the export directory




Step 3: the exporting progress and will be completed

3.9 Close Program

Click [Close] button to remove all blocks, a program attribute Restore Defaults. If the current program is not saved, you are prompted to save, as shown below:




☆ when the program has modified, the program name attached a asterisks, no change no asterisk, as shown below



3.10 Change Background

Click the [change the background] button, will pop-up dialog box, select a Picture and click [OK] button to change the background, you can remove the background image to check the none checkbox, as shown below:




3.11 Delete Block

Select the block to be deleted, click [Delete Block] button.

3.12 Change Resolution

Click [Resolution] drop-down box, select a resolution, operating area will automatically resize the resolution.



If the resolution is not in the list you want to target resolution setting, you can only create wizard manually input resolution value in the program, simply

press the "long x wide" mode settings.


3.13 Fine Tune

Under normal circumstances you can drag the mouse, set the size and position of the WYSIWYG area, numerical fine tune bar will follow the changes in settings for fine-tuning or exact value can be realized through the spin button, as shown below:



3.14 Element Panel

The main element type: Hybrid, video, flash, images, office documents, audio, text, web pages, and are related to the interaction [return], [Home]. It can be any combination of elements put together on operating area. As shown below:




① mixing container: used to play videos, pictures and text, you

can load multiple video, images, text, attributes of each individual creative control

- ② video container: used to play the video, you can load multiple video, sound can be controlled independently of each video
- ③ image container: used to play pictures, you can load multiple images can be controlled separately for each image playback time, transition effects
- ④ text container: for broadcast text, you can set the rest or vertical scrolling, you can set the text size, color, background color, etc.
- ⑤ Subtitle container: for lateral scrolling text, you can set the text size, color, background color, etc.
- 6 web container: used to play web content
- 7 office containers: used to play Word, Excel, PPT documents
- Back button: Touch query program, back to the previous program,
 you can set the button image
- Home button: touch inquiry program for direct return to the
 first stage program, you can set the button image


3.15 Editing block Content

Double-click the block or click [Edit Block] button to open dialog, Select File and Add / Remove files, can be set the playback settings, As shown below:



3.16 Play Settings panel

[playback settings] is mainly used to set the control parameters to play the file, the different types of files have different attributes, the image file can be set to single image playback duration, transition effects; when the video and Flash files can be set to play duration and volume; for text files can be set to play duration, font, size, color, scroll direction, speed and other parameters, as follows:




Text Settings

Web Page Settings




Subtitle Settings



3.17 Link Program

Link program playback function refers to a terminal with a touch screen during playback of the current program, tap the area of the screen to immediately play another program. The second program may be provided a link to the third program, thereby forming a series of related programs, when the touch screen idle for some time (default 60 seconds), the screen returns to the first program.

- ► In the container element right, select "Link Program" menu
- ► link the program as part of this program



3.18 Block to Full Screen

Select area, right click and select [Full Screen] menu, the current area to fill up the entire screen.

OK


Cancel

Chapter 4 program review

After transmission of the program will form a programming task, we can review the program, rejected, or delete operation.


4.1 Audit program interface

The program should be audited then can be sent to terminal, the auditor may be rejected or removed. State audit include: to audit, passed, refused. As shown below:




4.2 Review Program


Select the program in the program list, you can view the "Basic Information" of the program, "Play File", "Released terminal", as shown below:



Shows that the applicant of the program, duration, resolution and other information




Click the file name will automatically play the file in the preview area



Display the program which has been released to terminal group and state

4.3 Audit program


Select the program then click the reject or pass button, enter passed or rejected opinions about the program, as shown




☆ You can only review a single program one time

4.4 Delete Program

Select the program \rightarrow click [delete] \rightarrow click [ok]






4.5 Preview Program


Select a program → click [preview]

4.6 Release Program


Select a program, popup the release wizard, As shown below:



Step 1: Select Programs



Step 2: Select Terminal Groups



Step 3: select the playing start date time and end date time

[Priority (Insertion)] Check this box indicates the program on the selected


terminal group takes precedence over the same group unchecked programs, should be noted: the same period of time if the terminal groups on both high-priority programs and lower priority programs, the terminal will only play high-priority programs.

[Download Immediately] when received the command, the terminal will be immediately download the files included in the program from the server;

[free download] represents the period after the command is issued, the terminal will not be downloaded immediately, but wait until the free period of time to download, has avoid the congested the network in busy periods.


Chapter 5 terminal maintenance

Click on the main menu [Client Management] → [Terminal Maintenance] enter the interface, As shown below:




5.1 Add Terminal Group

Select the group you want to add subgroups, click [add], then enter the group name, click OK, as shown below:



5.2 Modify Group

Select the group you want to modify the group name and click [renamed] enter group name, as shown below:



5.3 Delete Group

Select the terminal to be deleted group, click Delete button, as shown below



- ☆ Terminals deleted group will automatically be moved to the deleted group's parent group below, as shown above, if delete "Changsha" group then all terminals under of "Changsha" will automatically move to the default group.
- ☆ "Default Group" and "Ungrouped Terminal" is a system group of self-built, can not be deleted.


5.4 Move Terminals

Select the terminal need to move, Click [Change Group] button, then select the target group, as shown below

App Ver Free Space


2.0.2.002 5.24 GB

2.0.2.002 5.26 GB



5.5 Remove Terminal

Select the terminal (multiple select), click [Remove Terminal] button, as shown below.






5.6 Status Monit


Real-time display terminals online status, the latest communication time, registration status, software version, and the total number of terminals, the number of online, the number of offline, as shown above

5.7 Configure Terminal


Choose to view edit terminal (may multiple select), Click [Configure Terminal] button to open the configure dialog. As shown below




Basic Configuration page, enter the name and address of terminal.



Sound and display page can set terminals' media volume, the period volume from start time to end time.



Working time page can be set the terminal's timing switch time, it can be set up five time period; when the terminal 24 hours of work for a long time, in order to periodically clear the system memory and restore the vitality of the system, the terminal can be set to automatically reboot once at restart time.



Set the terminal network transmission free time, when there is a terminal program files need to download it will automatically start the download process in the free time period. Download bandwidth limit the download speed does not exceed the value, to prevent the impact of bandwidth to other businesses in network.

5.8 Remote Shutdown

Select the shutdown terminal (multiple selection), click [Shut Down] button. As shown below



5.9 Reboot

Select the terminal need reboot(multiple selection), click [Reboot] button.

5.10 Shut0n

Select the terminal to boot(multiple selection), click [On SCR] button.


5.11 Remote ScreenShot


Select screenshots terminal (optional up to nine) Click [Remote Screenshot] button. As shown below



5.12 Remote Upgrade

Choose to upgrade terminals (multiple choice) and click [upgrade] then select the upgrade package, click OK. As shown below






5.13 Network Registration

Step 1:

Select the terminal to be registered (multiple choice), Click [Register] [export machine code], then select the save path, click OK. As shown below:






Step 2:


Exported .mac file sent to manufacturers, vendors return the registration code .ath file

Step 3:

The vendor returned .ath file import to management tool. Click [Register] [Import Registration Code] to open a dialog, select the register file and click [Open], as shown below



After importing the system prompts "successfully imported XX terminals License", if the registration document is malformed then tips




After Importing the registration code the management tool shows which terminal is registered; In player terminal's setting

interface can also see if the terminal has been registered; in the case of offline when the small number of registered terminals can also press this document part 1.6.3 [Single manual registration] to manually regist.


Chapter 6 Terminal Release

Click on the main menu [Terminal Management] → [Terminal Release], enter the terminal release interface, as shown below




6.1 Release Program


Click [Release Program] button, popup the release program guide, as shown below:



Step 1: Select Programs



Step 2: Select the terminal groups to release



Step 3: Select playback start and end date and time and download time

[Priority (Insertion)] Check this box indicates the program on the selected terminal group takes precedence over the same group unchecked programs, should be noted: the same period of time if the terminal groups on both high-priority programs and lower priority programs, the terminal will only play high-priority programs.

[Download Immediately] when received the command, the terminal will be immediately download the files included in the program from the server;


[free download] represents the period after the command is issued, the terminal will not be downloaded immediately, but wait until the free period of time to download, has avoid the congested the network in busy periods.

☆ only the audited program terminal will play

6.2 View Program

Select the terminal grouping, Click [View Program] button, pop-up a dialog box

to view the program, as shown below




The dialog box displays on the current terminal group and all of its ancestors group has published programs, displays the name of each program, the size, duration, playback start and end dates, start and end time, priority, schedule status, approval status, publisher and other information. Click [Withdraw] button to cancel the program on the terminal group or ancestral group, click [Release] button will bring up a program guide release new programs, click [Up] or [Down] button to adjust the program order of play on the same terminal group, click [preview] window will pop-up preview of the selected program.

☆ [Up] and [Down] button can adjust the order of the same group only, can not be adjusted between different groups.

6.3 Insert-Play Subtitles


Terminal system can be insertion-play programs and scrolling marquee, after the instruction sent then send a cancel command before insertion-play is complete, the insertion-play can be stopped immediately, Click [Insertion-Play] → [Insertion-play subtitles], then pops up a dialog box, as shown below



Enter the text in the edit field or click the [Import] button to select a TXT text file into text, click the font color edit box, automatically pop up a dialog box, you can pick a color as text color, when click the font color in the edit box for second time, you can enter or paste the color value in the format beginning with a # sign, followed by six 0 ~ F. Similar changes background color. Font color operation can also choose transparent radio button to set the insertion-play subtitle transparent display. Speed is divided into 1-5, the larger the number, the faster. Subtitle repeated several times expressed. [Insertion-Play immediately] and [Insertion-play Timing] are a pair of radio buttons, when you select [Insertion-Play Immediately] after the instruction transmitting terminal will immediately download and play, and [Insertion-Play Timing], after sending the instruction the content to be download then wait to play until the setting time reached.

6.4 Insertion-Play Program

Click [Insertion Play] → [Insertion-Play Program], pop-up the dialog box, then select a program, the following chart




[Insertion-Play immediately] and [Insertion-play Timing] are a pair of radio buttons, when you select [Insertion-Play Immediately] after the instruction transmitting terminal will immediately download and play, and [Insertion-Play Timing], after sending the instruction the content to be download then wait to play until the setting time reached.

6.5 Cancel Insertion Play

Click [Insertion Play] → [Cancel Insertion-Play] button, you can cancel all the insertion-play subtitle and program, including the timing insertion-play that the time not yet reached.

6.6 Terminal File

Click [Terminal File] → [Terminal File], the file dialog will pop up, the system automatically displays the terminal's all files in its media path, as shown below




Select the file, click [Delete Files] button these files on the terminal will be deleted, click [Delete Expired Files] button to delete all expired files on the terminal. Click the Refresh button to re-display the file on the terminal.

Expired Files indicating the current program task and insertion-play task does not contain these file


6.7 Delete Files

In the terminal file dialog you can select and delete the single terminal's files, there is another way to delete multi-terminals' expired files, select the terminal (optional arbitrary number) Click [Terminal File] → [Delete Expired Files] button to delete outdated files, the pop-up dialog box, as shown below, click OK to delete the selected terminals expired files.




6.8 Download Progress

Download progress and speeds of the respective terminals. As shown below



6.9 Play Logs


Select a terminal (only one) → click [Play Log] button, as shown below



Dialog box displays the files that the terminal has been play, and play times by each day

6.10 Terminal Run Log

Select a terminal (only one) → click [Run Log] button, as shown below



The dialog box shows the date and time of the log, terminal number, grade and log information content, information grade is divided into four levels: information, warnings, errors, fatal.

Chapter 7 FTP user


Click to the right of the main interface [User Management] → [FTP User] button to enter the FTP user management window, as shown below



7.1 Add FTP User

Click [add] button, pop-up [add FTP user] dialog box, as shown below


- 1) FTP IP, Port
- 2 User, Password
- 3 Click OK



After the server installation and first login management tool, the system will automatically pop up FTP configuration dialog box, IP address of the FTP should be consistent with the actual IP address of the FTP, if the inconsistency will lead to the management tool can not upload files, the terminals can not download the file.

7.2 Modify FTP User

(1) Choose to modify the FTP user, click [Modify], as shown below



When the IP address of the actual FTP, port number, user name, password has been changed, the modifications must also be synchronized on management tool, keeping consistent with the actual FTP, if the inconsistency will result in the management tool was unable to upload files and the terminals can not download the file.

☆ FTP address, fill out the real IP address of FTP server when deployed in a WAN IP address here to fill in the WAN, when deployed in a local area network server then complete LAN IP address. User name and password must be same as the part [1.2] FTP server user name and password entered, otherwise the management tool and player terminals will not upload and download files.


7.3 Delete FTP User

Select the FTP user you want to delete, click [Delete] button to pop-up a dialog box, click OK, as shown below



Chapter 8 Role Management


Click to the right of the main interface [User Management] → [Role Management] button to enter the role management window, as shown below




8.1 Add Role

Click [Add] button, pop-up [Add Role Wizard] dialog box, as shown below


- 1) Input Role Name
- 2 Check the role has permission
- ③ Click OK button





8.2 Modify Role

(1) Select the role you want to modify, check or remove permissions, click [Save] button, as shown below




8.3 Delete Role

Select the role to delete (multiple choice), click [Delete] button, then pop-up prompt box, click OK, as shown below



Chapter 9 User Management


Click to the right of the main interface [User Management] → [Role Management], enter the role management window, as shown below




9.1 Add User

Click [Add] button, pop-up [Add User Wizard] dialog box, as shown below


- ① Enter the user name, password and other information
- ② Select the FTP user and the new user management terminal grouping
- 3 Click [Finish] button







9.2 Modify User

Select the user, click [Edit User] button, as shown below








9.3 Delete User

Select the user to delete (multiple choice), click [Delete User] button, as shown


below



Chapter 10 Log Analysis

10.1 Play Log


Click [Log Analysis] → [Play Log], enter the play log analysis interface



[Group] drop-down box lists all group managed by current user, [Name] drop-down box lists all the resource file name, click [query] button will inquiries combination of these conditions group, name, play the file, starting and ending dates

10.2 Run Log

Click [Log analysis] → [Run Log], enter the run log analysis interface



[Group] drop-down box lists all group managed by current user, [name] drop-down box lists all terminals in current selected group, [Type] drop-down box lists four types, they are information, warning, error, fatal. [keyword] input box can be filled with logs any key words, for example: "Download failed", "2.txt", use these keyword to query using a fuzzy search method, click [query] button will query the database by combined conditions name, type, keywords, start and end dates.

Proper use of the keyword query can help us to retrieve a lot of interesting information, for example, enter "Terminal offline" can help us to query all terminal's offline events in a period, to determine if the terminal is an isolated phenomenon offline or a local or global phenomenon.

10.3 Operation Log

Click [Log Analysis] → [User Logs], enter the user log analysis interface.




[User] drop-down box lists all users in the system, [keyword] input box can be filled with logs any key words, such as: "Login", "Edit program" and so on, click [Query] button will querys by combined conditions users, keywords, start and end dates.

Chapter 11 System Management

11.1 Modify System Settings

Click to the right of the main interface [System Settings] → [System Settings], enter the System Setup window, as shown below




11.2 Modify Settings

Click the button

in the upper right corner of the window, pop-up

settings dialog box, as shown below



Check [boot] box will be set the management tool if start automatically when the computer starts; click [Change Directory] opens the Folder dialog box, select the directory as a directory to store temporary files; click [Clear] to clears directory all files and directories in the temporary directory

Temporary directory to store image files used by the function program edit, the file to be displayed in the background, and temp files or folders generated by converting Office documents.

11.3 Modify Password

Click on the top right corner of the main window [Change Password] button, as shown below


- 1 Input new password and old password
- (2) Click OK






11.4 Exit Management Tool

Top right, click the Close button, click "OK" to exit the system, can also click on the close button of the window to exit the system. As shown below






Chapter 12 Software Uninstall

12.1 Uninstall Management Tool

Click [Start] → [All Programs] → [Digital Signage] → [Management Tool] → [Uninstall] to uninstall the management tool, after the uninstall is complete, as shown below



12.2 Uninstall Server

Click [Start] → [All Programs] → [Digital Signage] → [Server]
→ [Uninstall]

Uninstall is complete, as shown below

